The solution to the problem that Printer spites out a couple of blank labels

Problem: The solution to the problem that Printer spites out a couple of blank labels

- **Possible cause 1:** The print layer doesn't face up
- **Possible cause 2:** Incorrect position of printing.
- **Solution:**

  1. Please make sure that the print layer faces up before printing.
  2. Long press on feed button for around 3 seconds until printer beep one noise, release your finger. Printer will automatically calibrate the place of the labels, which keeps back on forth several times, then hold on the correct position.